

Grommet NFC Tag

A how-to guide for applying grommet NFC tags to round bar and steel carabiners.

Where to apply

Under the locking mechanism of the gate, providing it doesn't block or obstruct the functionality. They also work nicely on the spine. Avoid placing on any load bearing areas.



How to apply

- Drop the grommet into warm water briefly (60 sec) to soften the material.
- Check if you should face the proud side of the tag inward or outward (see below).
- Use a solid edge (like a wooden bench) to slide the grommet onto your 'biner into the desired location.



✓ Screwgate



✓ Spine



✗ Load-bearing / rope running surface

- Do**
- Ensure the grommet fits tightly and does not shift once fitted (let it set until cooled).
 - Position the tag under the gate locking mechanism if possible, otherwise on the spine.
 - Face the raised ('proud') side outward if your phone's NFC reader is not in the top corner.

- Don't**
- Use glue, its designed to hold securely without adhesive.
 - Install the tag on any load bearing or rope-running surfaces.
 - Allow the tag to interfere with the locking gate mechanism, or any operational function.
 - Ignore movement over time, re-seat if needed.

This tag works well on equipment like:

Singing Rock D Steel Connector; Edelrid Steel HMS; DMM Oval Steel; At Height UK K10; Rock Exotica Rock D

