Quick Start Guide - Barcode Scanner

This scanner works in 'Keyboard Emulation' mode, meaning it types scanned codes into any field where your cursor is placed.



Make sure the device is charged. A flashing blue light indicates low battery, and five beeps followed by shutdown means it's out of power.

Wireless Connection (Base Unit) - Default

- Plug the USB cable into your computer.
- Press the trigger on the Scanner.
- You will be able to scan barcodes into the laptop.

Bluetooth Mode - Optional

- Press the trigger button to activate / wake the scanner.
- Press and hold the trigger for 8 seconds to set it into Bluetooth mode.
- Open Bluetooth settings on your device and search for the 'Scannable HID'.

Scan this QR code for more settings

